



## U-Mo bare foil rolling progress for FRM II conversion

**BUDUCAN K.<sup>1,2</sup>, LORAND S.<sup>1</sup>, STEPNIK B.<sup>1</sup>, RONTARD C.<sup>1</sup>, GAUCHE F.<sup>1</sup>  
BAUMEISTER B.<sup>2</sup>, SCHWARZ C.<sup>2</sup>, CHEMNITZ T.<sup>2</sup>, PETRY W.<sup>2</sup>**

1: Framatome (CERCA division)

2 Rue Professeur Jean Bernard, 69007 Lyon – France

2: Forschungs-Neutronenquelle Heinz Maier-Leibnitz (FRM II) Technische Universität München, Lichtenbergstr. 1,  
85747 Garching – Germany

**Vienna – RERTR 2022 – 03/10/2022**

# CONTENT

- 01 .** FRM II conversion purposes
- 02 .** U-Mo flat rolling process
- 03 .** U-Mo bare foil results
- 04 .** Conclusion & perspectives

# FRM II conversion purposes

## Current situation



Figure 1: FRM II research reactor (Garching, Germany)

# FRM II conversion purposes

## Current situation



Figure 1: FRM II research reactor (Garching, Germany)




Figure 2: FRM II pool with fuel assembly scheme

# FRM II conversion purposes

## Fuel conversion



Figure 3: Transverse cut of actual FRM II fuel

# FRM II conversion purposes

## Fuel conversion




Figure 3: Transverse cut of actual FRM II fuel




Figure 4: New FRM II fuel composition

# FRM II conversion purposes

## New fuel plate manufacturing process in Framatome





Figure 5: Manufacturing process flow for the new FRM II fuel

# FRM II conversion purposes


## Progress & schedule of R&D fuel development






# FRM II conversion purposes

## Progress & schedule of R&D fuel development




# FRM II conversion purposes

## Focus on for FUTURE-MONO 1 irradiation



# FRM II conversion purposes

## New fuel plate manufacturing process in Framatome



Focus on :



- hot flat rolling
- U-Mo bare foil removing

# U-Mo flat rolling process

## Equipment available for U-Mo rolling

- **Hot rolling mill characteristics:**
  - Rolling speed and roll gap controllable
  - Max. & min thickness: 20 to 0.1 mm
  - 2-Hi & 4-Hi according foil thickness



Figure 6: Hot rolling mill in CERCA lab

# U-Mo flat rolling process

## Equipment available for U-Mo rolling

### ▪ Hot rolling mill characteristics:

- Rolling speed and roll gap controllable
- Max. & min thickness: 20 to 0.1 mm
- 2-Hi & 4-Hi according foil thickness

### ▪ Cold rolling mill characteristics:

- Rolling speed and roll gap controllable
- Max & min thickness: 1 to 0.1 mm
- 4-Hi for foil finalization



Figure 6: Hot rolling mill in CERCA lab



Figure 7: Cold rolling mill into glovebox

# U-Mo flat rolling process

## Equipment available for U-Mo rolling

- **Hot rolling mill characteristics:**
  - Rolling speed and roll gap controllable
  - Max. & min thickness: 20 to 0.1 mm
  - 2-Hi & 4-Hi according foil thickness



Figure 6: Hot rolling mill in CERCA lab

# U-Mo flat rolling process

## Hot flat rolling process manufacturing description





Figure 8: Flat rolling step for U-Mo bare foil manufacturing

# U-Mo flat rolling process

## Hot flat rolling process manufacturing description




DEVELOPMENT OF LASER  
PROCESSES ON U-10Mo  
MONOLITHIC FUEL FABRICATION  
PROCESS AT FRAMATOME  
(CERCA BUSINESS LINE)



# U-Mo flat rolling process

## Hot flat rolling process manufacturing description



U-MO BARE FOIL ROLLING PROGRESS FOR FRM II CONVERSION - BUDUCAN Kevin - RERTR 2022 - 03/10/2022 © Framatome - All rights reserved

C0 - Distribution libre / Export Control - AL : N ECCN : N

# U-Mo flat rolling process

U-Mo bare foil hot rolled laser removed inside glovebox




Figure 9: Decaning of U-Mo bare foil after hot rolling

# U-Mo flat rolling process

U-Mo bare foil hot rolled laser removed inside glovebox




Figure 9: Decaning of U-Mo bare foil after hot rolling


# U-Mo flat rolling process

## U-Mo bare foil appearance after hot rolling



### Foil A

- Length x Width : 550 x 100 mm
- Thickness : 0.600 mm



### Foil B

- Length x Width : 350 x 100 mm
- Thickness : 0.850 mm

Figure 10: Flat rolling step for U-Mo bare foil manufacturing

# U-Mo bare foil results

## Hot rolling scheme for uranium & inert tests

- Assembly (canister + ingot) thickness reduced to **less than 1.5 mm**
- Working temperature: **650°C**
- **Constant rolling speed and load deflection (as RRFM 2021 experiments)** during the overall process

# U-Mo bare foil results

## Comparison with inert material

- Assembly (canister + ingot) thickness reduced to **less than 1.5 mm**
- Working temperature: **650°C**
- **Constant rolling speed and load deflection (as RRFM 2021 experiments)** during the overall process




Figure 11: Inert foil decanned by laser cutting

# U-Mo bare foil results

## Comparison with inert material

- High similarity on loads between inert tests & uranium
  - Thickness measured slightly higher for uranium than inert
- **Hot rolling scheme of inert could be used for depleted uranium alloy**



# U-Mo bare foil results

Measurement map for both thickness & waviness profile



**Legend:**

● Thickness point measurement

Figure 12: Experimental measurements map for both foil waviness and thickness



# U-Mo bare foil results

## Measurement map for both thickness & waviness profile





Figure 12: Experimental measurements map for both foil waviness and thickness

# U-Mo bare foil results

## U-Mo bare foil thickness distribution



A

Figure 13: U-Mo foil thickness heatmap from thickness mean value

# U-Mo bare foil results

## U-Mo bare foil thickness distribution




Figure 13: U-Mo foil thickness heatmap from thickness mean value


# U-Mo bare foil results

## U-Mo bare foil thickness distribution

- Mainly negative variation on edges & positive on center
  - Random part variation due to ingot geometry and strength applying
- Resolving by cold rolling process to homogenize thickness and by laser cutting of edge parts

# U-Mo bare foil results

## U-Mo bare foil waviness profile




A

Figure 14: Waviness profile for U-Mo foil on different foil sides

# U-Mo bare foil results

## U-Mo bare foil waviness profile



B

Figure 14: Waviness profile for U-Mo foil on different foil sides

# U-Mo bare foil results

## U-Mo bare foil waviness profile

- Extremum values on both side of hot rolled foil
  - Mostly constant variation from reference between right, middle and left side
- Resolving by cold rolling process to improve flatness, heat treatment under loads and laser cutting of both side could resolve theses issues

# U-Mo bare foil results

Global foil quality: thermal gradient




Figure 15: Thermal impact on U-Mo foil after hot rolling



# U-Mo bare foil results

Global foil quality: edge cracks

Edge foil cracks




Figure 16: U-Mo bare foil defects after hot rolling process

# U-Mo bare foil results

Global foil quality: edge scratches

Edge foil scratches



Figure 16: U-Mo bare foil defects after hot rolling process

# U-Mo bare foil results

## Global foil quality: edge scratches

- Temperature gradient which affects surface condition (oxide)
  - Cracks and scratches on edge foil due to friction, contact with canister, roll strength and mechanical behavior of ingot
- Resolving by laser cutting defects after hot rolling & better surface aspect and thickness control of ingot prior to hot rolling**

# Conclusions

- Hot rolling mill is implemented and well working in uranium in CERCA laboratory;
- Feasibility of hot rolled U-Mo bare foil in CERCA is demonstrated;
- Global quality of U-Mo bare foil produced will be improved for next manufacturing steps (waviness, thickness distribution, surface condition).

# Conclusions


- Hot rolling mill is implemented and well working in uranium in CERCA laboratory;
- Feasibility of hot rolled U-Mo bare foil in CERCA is demonstrated;
- Global quality of U-Mo bare foil produced will be improved for next manufacturing steps (waviness, thickness distribution, surface condition).

# Perspectives

- Hot-rolled foil characterization : microstructure, mechanical & thermal properties;
- Cold rolling process study for bare foil finalization;
- Improving the global process for further industrialization.

**framato**me

**Thank You!**



Any reproduction, alteration, transmission to any third party or publication in whole or in part of this document and/or its content is prohibited unless Framatome has provided its prior and written consent.

This document and any information it contains shall not be used for any other purpose than the one for which they were provided.

Legal and disciplinary actions may be taken against any infringer and/or any person breaching the aforementioned obligations.